Solvent Suppression using TopSpin 3.x

updated: 18 July 2022 (cgf)

Brief Summary

There are number of solvent suppression schemes used in NMR, and the technical details can become extensive. Here is a brief list of suggestions:

presaturation – can give cleanest, or at least, narrowest suppression, but significantly reduces exchangeable protons; sequence variations, such as using a composite pulse, assist in reducing residual water

noesy1d presat - can provide cleaner baselines; used in many metabolomics studies

	Bruker's LC-NMR experiments use noesy1d-presat, and are implemented in the facility in IconNMR; see this <u>document</u> for more							
purge pr	resat	 a relatively new method of presaturation, touted as superior to standard presat for quantitative studies (we have yet to test this assertion here) 						
wet		 a prominent method used with mixed solvents (multiple-peak suppression); can reduce intensity of exchangeable protons 						
watergat 3-9-19 w5	te)	 a number of forms exist: the basic type requires optimization, but high-quality the most commonly used wg variant; no effect on exchangeable protons a wg variant similar to 3-9-19, but narrower notch about solvent 						
excitatio	n sculj	oting – any solvent suppression technique that uses spin/gradient echoes — e.g., watergate flavors — can be run twice in a row; this double pulse-field gradient spin echo (DPFGSE) method produces excellent suppression (square of the						

A significant issue with solvent suppression on Bruker spectrometers is which variants are available in the experiment you really need. **purge** may run great in a 1 H 1d, but does not exist (currently) in any 2D flavor. See Table 1 for an up-to-date listing of sequences available at UWChemNMR.

single method), but also a broader notch bandwidth about the solvent peak

Suggestions for how to choose:

- i. If exchangeable protons are important, use a watergate flavor.
 - If important solute peaks are close to the solvent, but you must also observe exchangeables, use the narrowest bandwidth (largest d19) possible. Do not use excitation sculpting.
 - If suppression is critical with exchangeables, use excitation sculpting.
- ii. To observe solute peaks close to the solvent peak, and there are no (important) exchangeables, use a low-power presat flavor.
- iii. If it is crucial to completely eliminate the solvent peak, use an excitation sculpting flavor.
- iv. *If multiple solvent peaks must be reduced*, use wet or presat using the selection 1D options. Start with information provided below in section **G**.

v. It is easy to try various solvent suppression flavors in the ¹H 1D versions. <u>Do this!</u> You will need to spend time collecting 1D spectra to judge the quality of your shims and suppression. So experiment with different types within the main categories stated above. Base the final choice (or two) on these 1D experiments. July 2022: see NMR staff for updates that include LC-NMR experiments.

A. <u>Initial Setup:</u>

1. Always start by acquiring a one-scan ¹H spectrum.

It is not required, but best to run solvent suppression experiments on-resonance to the solvent peak. If you believe this is not optimal, find cgfry for further discussion.

- 2. Put the solvent peak on-resonance by:
 - a) expand about the solvent peak enough that you can easily see the center
 - b) click \checkmark and then left-click with the cursor in the middle of the solvent peak
 - c) choose o1
 - d) retake the one-scan ¹H spectrum to verify that the peak is in the center of the spectrum.
 - c) To obtain the most accurate **o1** value:
 - \rightarrow rpar the parameter set: solvsup_setup.UW (a standard presat exp optimized for gs)
 - \rightarrow enter the approximate **o1** value from above, then type:

gs₊l

Adjust o1 until the FID is minimized.

3. Write down the value for **o1** in Hz.

B. <u>Presaturation:</u>

- 1. In the new expno, run **ased** and change the first parameter PULPROG to **zgpr**. Or read in the parameter set: **H1_presat.UW** and set **o1** as found in step A.3.
- 2. The critical new parameter with all presaturation techniques is **plw9** (or **plw32** in sequences asking for lower power presat), which will perform a low-power cw pulse on-resonance. You can raise the power of this parameter to decrease the intensity of the residual signal, but setting it too high may damage the probe!

plw9 \leq 0.3 mWatts (\leq 0.0003 in the 1st box on the ased screen)pldb9 \geq 35 -dBW (value in 2nd box on the ased screen should \geq 35)

- 3. Run rga prior to doing zg.
- 4. Better data can usually be obtained by using a composite pulse: H1_presat-cp.UW (PULPROG=zgcppr.UW).

C. noesygppr1d Presaturation:

- 1. Do the same steps as in B, but read in the parameter set H1_presat-noesy1d.UW (PULPROG=noesygppr1d.UW).
- 2. Change **o1** to match the value found in A.3.
- 3. Run rga prior to doing zg.
- 4. **plw9** again might be smaller than optimal. Same conditions apply as in B.2.

D. purge Presaturation:

- 1. Do the same steps as in B, but read in the parameter set H1_presat-purge.UW (PULPROG=zgpurge.UW).
- 2. Change **o1** to match the value found in A.3.
- 3. Run rga prior to doing zg.

E. watergate 3-9-19 suppression:

- 1. Do the same steps as in B, but read in the parameter set H1_3919.UW or H1_3919es.UW (PULPROG=p3919gp.UW or p3919gpes.UW).
- 2. Change **o1** to match the value found in A.3.
- 3. Check $d19 = 1/(2\Delta)$ where Δ =distance to null in Hz from the solvent peak. Narrowest bandwidth may attenuate solute peaks most downfield and upfield, but will also give the narrowest (sharpest) solvent notch.
- 4. Run rga prior to doing zg.

F. watergate w5 suppression:

- 1. Do the same steps as in B, but read in the parameter set H1_W5.UW or H1_W5es.UW (PULPROG=zggpw5.UW or zggpw5es.UW)
- 2. Change **o1** to match the value found in A.3.
- 3. Check $d19 = 1/(2\Delta)$ where Δ =distance to null in Hz from the solvent peak. Narrowest bandwidth may attenuate solute peaks most downfield and upfield, but will also give the narrowest (sharpest) solvent notch.
- 4. Run rga prior to doing zg.

F. wet suppression:

1. Do the same steps as in B, but read in the parameter set H1_wet.UW or H1_wetdc.UW (PULPROG=wetdc nodec.UW or wetdc.UW).

Use **H1_wet.UW** to suppress water, or for an organic solvent when peaks close to the solvent are not present. Use **H1_wetdc.UW** for organic solvents when ¹³C satellites are problematic.

2. Change **o1** to match the value found in A.3.

3. The power of the 1st wet pulse is strongly affected by cryoprobes, and even normal-coil probes. For cryoprobes, it is mandatory to optimized the power level of this pulse; we recommend optimization for all uses of wet on Bruker equipment. It is relatively simple to perform:

Optimization of wet power level spdb7:

- a) Run rga. Good suppression should always lead to $rg \ge 20$; the goal is to do better than that.
- b) Check that $\mathbf{aq} = 1-2$ s, and $\mathbf{d1} = 1-2$ s.
- c) Enter Bruker's real-time optimization routine: gs↓

When you first enter, the rg may be quite poor. An example setup is shown below:



d) Adjust the Shape parameter **spdb7**, which is the power of the 1st wet pulse. On our 600 with the TCI cryoprobe, the power must be raised 5 to 10 dB (oddly, to smaller values) to obtain reasonable suppression. The start a coarse adjustment, ±1 dB, is shown below:



- e) It shouldn't take long to achieve a much decreased fid size, viewed visually or by using the FIDAREA number in the upper right. At the best 1 dB position, Save and then Stop the gs run. Redo an rga, ; you should now achieve a much better rg (in this case, rg=90.5).
- f) Re-enter **gs**. Go back to **Shape** and click on **SPdB7**. Change the sensitivity to 0.1, and adjust to minimum fidarea. See the start and end example screencaps below.



1- GS: test_lcnmr-solvsup	800 1 /home/fry/av60	10							r ⊠ ⊠
Spectrum ProcPars	AcquPars Title Pi	ulseProg Peaks Integral:	Sample	Structure F	lot Fid	Acqu			
Frequency Pulse Pow	ver		t						
Offset Receive	er Gain Pulse		<u>×</u>					Acquiciti	
Shape CorPl	hase Delay	Index = 685771 - 686509						Acquisici	[""
	SPdB7	Value = 29.70 rel						PULPROG = NUC1 = 1	wetdc
Shape								SW = 20.0	4 -
O SPOAL10								SWH = 120 TD = 7691	.84
⊖ SPOAL7	adjust							ETDAREA -	12728810
O SPOAL8	max: 52.317							TIVANCA	12720010
O SPOAL9									-
O SPOFFS10 [Hz]	l i i								-
O SPOFFS7 [Hz]									- vi
O SPOFFS8 [Hz]	l l								-
SPOFFS9 [Hz]									
SPW10 [W]									-
O SPW7 [W]									
SPW8 [W]	L L								-
SPW9 [W]	Υ	Source and							-
O SPdB10 [dB]									
SPdB7 [dB]	I								_ u
O SPdB8 [dB]	1								
O SPdB9 [dB]	UE								-
	min: 42 317								
	40.017								10
<u>S</u> ave S <u>a</u> ve a	ll <u>R</u> estore								- '
Restore all	Stop								-
ngstore un	01 <u>0</u> p								-
		50000							Ĺ
	a constant and the same			5	· ·		10	15	
		2	0.				7.0	1.3	[9]

f) **Save** and **Stop**. High quality wet suppression should now be achieved. Keep ds large, e.g, ds=24, if you are decoupling carbon satellites (H1_wetdc.UW).

H. Multiple-peak solvent suppression:

This section uses selective 1D setup in TopSpin to create shapes for multiple-peak suppression. For more detail about selective 1D experiments, see section B of the notes at:

http://www.chem.wisc.edu/~cic/nmr/Guides/Ba3vug/HW637/HW5_Av400-sel1DbyTopSpin.pdf

Two types of suppression are provided: **wet** and **presat**. **Wet** selection is preferred if exchangeable protons are important, and especially if quantitative information is needed from exchangeables. Otherwise, as is true in general for all solvent suppression types, use **presat**.

- 1. Acquire a 1-scan proton spectrum as described in section A.
- 2. Integrate the solvent peaks to be suppressed in the proton spectrum. For **wet** suppression, keep the integral regions not too small (>20Hz; ~60 Hz is a good width), and not too dissimilar in width. For **presat** suppression, choose relatively narrow width/integrals (~15 Hz) in all cases.
- 3. click on: CREATE DATASETS

and choose wet or presat toward the bottom of the list. Save the integrals using Save As... reg.

4. For wet, optimize spdb7 using the method described above in section F.

Pulse Sequence² Parameter Set¹ **Suppression Type** Bruker: par; pp **Critical Parameters** comments 1D setup solvsup setup.UW presaturation (d1) zgpr.UW obtain **o1** optimized for gs none; zgpr **1D** experiments H1 presat.UW presaturation (d1) zgpr30.UW $plw9 < 0.3 mW^{3}$ saturates exchangeable ¹H; none; zgpr presat types have narrowest suppression of base types H1 presat-cp.UW presaturation (d1) with zgcppr.UW $plw9 \le 0.3 mW^3$ none; zgcppr (zgcpgppr; -better baselines than zgpr composite pulse zgcpfppr) H1 presat-noesy1d.UW presaturation (d1+d8) during noesygppr1d.UW -popular in metabolomics $plw9 < 0.3 mW^{3}$ WATERSUP: noesy1d sequence d8 typically ≤ 10 ms noesygppr1d H1 presat-purge.UW presaturation (d1) with gradient zgpurge.UW $plw9 \le 0.3 mW^3$ -better for quantitation(?) none; zgpurge echoes H1 wet.UW wet for water wetdc nodec.UW manually optimize spdb7 good suppression, small none to 0.1 dB effect on exchangeables H1 wetdc.UW wet with suppression of organic manually optimize spdb7 CMC WET good suppression, small wetdc.UW solvent's ¹³C satellite to 0.1 dB effect on exchangeables H1 3919.UW watergate 3919 (W3) p3919gp.UW P3919GP; p3919gp (soft most common watergate $d19 = 1/(2\Delta)^4$ (soft variant: zggpwg) v.: ZGGPWG) H1 3919es.UW watergate 3919 (W3) with p3919esgp.UW -excellent suppression $d19 = 1/(2\Delta)^4$ none; none excitation sculpting (W5es better small MW) H1 W5.UW zggpw5.UW watergate W5 –narrower notch than 3919 $d19 = 1/(2\Delta)^4$ none; none (W3), but longer sequence H1 W5es.UW watergate W5 with excitation zggpw5es.UW -best suppression of base $d19 = 1/(2\Delta)^4$ none; zggpw5 sculpting sequences 2D coherence exps HC hsqc-edited.UW coherence gradients hsqcedetgpsisp2p3.UW $aq \le 0.3s$ HSOCEDETGPSISP2.35 ¹H-¹³C hsqc coherence HC hsqc-nonedited.UW hsqcetgpsisp2p2.UW HSQCETGPSISP.2⁵ gradients usually provide $aq \le 0.3s$ sufficient suppression 2D presat exps cosygpprqf.UW cosy with presat (d1) none; cosygpprqf magnitude-mode cosy HH cosy2d presat.UW $plw9 \le 0.3 mW^3$ HH dqfcosy2d-presat.UW DQFcosy with presat (d1) cosydfphpr.UW $plw9 \le 0.3 mW^3$ none; cosydfphpr non-gradient dqf HH tocsy2d-presat.UW tocsy with presat (d1) and zeromlevgpphprzf.UW $plw9 \le 0.3 mW^3$; $d9 \le$ none; mlevgpphprzf good 2d tocsy sequence quantum filter 0.2s HH noesy2d-presat.UW noesy with presat (d1+d8/mix) $plw9 \leq 0.3 mW^3$; $d8 \leq$ good 2d noesy sequence noesygpphpr.UW none; noesygpphpr T₁(shortest of interest) HH roesy2d-presat.UW $plw9 \le 0.3 mW^{3}; P15 \le$ roesy with presat (d1) roesyphprp2.UW ROESYPHPR; tic-toc spinlock; cw presat

Table 1. Solvent Suppression parameter sets and pulse sequences available at the UWChemNMR Facility; updated 29 July 2015.

Solvent Suppression using To	ppSpin 3.x				
			500000 (µs)	roesyphpr.2	
HC_hsqc's	see 2D Coherence exps above				
HC_hmbc-presat.UW	hmbc with presat (d1)	hmbcgplpndprqf.UW	$plw9 \le 0.3 \text{mW}^3; \text{ cnst13}$ $(J_{CH} \sim 3 \text{ to 12}; \text{ default 8})$	none; hmbcgplpndprqf	1-bond filtered; coherence gradients; cw presat
HN_hsqc-presat.UW	coherence gradients + presat (d1)	hsqcetgpprsisp2p2.UW	$\begin{array}{l} plw9 \leq 0.3 mW^{3}; aq \leq \\ 0.3 s \end{array}$	none; hsqcetgpprsisp2.2	coherence grads not enough suppression in HN hsqc
HN_hmbc-presat.UW	coherence gradients + presat (d1)	hmbcgplpndprqf.UW		HMBCGP_15N; hmbcgplpndprqf	coherence grads not enough suppression in HN hmbc
2D watergate exps					
HH_dqfcosy-3919.UW	3919 watergate ending sequence + low-power presat (d1)	cosydfgpph19.UW	$d19 = 1/(2\Delta)^4$; plw32 \leq 0.3mW ³	COSYDFGPPH19; cosydfgpph19	set plw32=0 (pldb32=1000) if exchangeable protons are reduced too much
HH_tocsy2d-3919.UW	3919 watergate ending sequence	mlevgpph19.UW	$d19 = 1/(2\Delta)^4; d9 \le 0.2s$	DIPSI2GPPH19; mlevgpph19 ⁶	dipsi spinlock in our hands has been inferior to mlev
HH_tocsy2d-W5es.UW	W5 + excitation sculpting ending sequence	mlevgpphw5es.UW	$d19 = 1/(2\Delta)^4; d9 \le 0.2s$	none; mlevgpphw5	superior suppression and baseline than 3919; but longer (not for large MW)
HH_noesy2d-3919.UW	3919 watergate ending sequence	noesygpph19.UW	$d19 = 1/(2\Delta)^4$; $d8 \le T_1$ (shortest of interest)	NOESYGPPH19SW; noesygpph19	
HH_noesy2d-W5es.UW	W5 + excitation sculpting ending sequence + low-power presat (d1)	noesygpphw5es.UW	$d19 = 1/(2\Delta)^4; d8 \le T_1(\text{shortest of interest});$ plw32 \le 0.3mW ³	none; noesygpphw5	set plw32=0 (pldb32=1000) if exchangeable protons are reduced too much
HH_roesy2d_3919.UW	3919 watergate ending sequence	roesygpph19p2.UW	d19 = $1/(2\Delta)^4$; P15 \leq 500000 (µs)	none; roesygpph19.2	

July 2022: see NMR staff for updates that include LC-NMR experiments.

¹.UW parameter sets often have parameters better optimized than the base Bruker setup. E.g., d1=2 or 3s (rather than ~1s), as is appropriate for small molecules; another example is d19=1/(2*5ppm) set according to field strength).

².UW pulse sequences often have protections coded in: $\mathbf{aq} \le 0.3$ s is in all hsqc sequences; $\mathbf{d9} \le 0.2$ s is in all tocsy sequences (we're looking as to how to do plw9 ≤ 0.3 mW). .UW sequences also have updated comments that will show in **ased** listings.

³ Or equivalently, pldb9 (or pldb32) \geq 35.

⁴ Δ = distance in Hz to next null from **o1** (or **o1p**); nulls will occur at $\pm n\Delta$, where *n*=0,1,2,3,...

⁵ Same sequence appended by _ADIA is best for 600 MHz and higher. The same _ADIA parameter sets can be used at low field without negative effects (and are used in the .UW sequences).

⁶ DIPSI2GPPH19 uses a difference pulse sequence, dipsi2gpph19, than stated here. In our hands so far, dipsi spinlocks have been inferior to mlev spinlocks. Our observations have been limited (as of July 2015), and results may be probe and field dependent. So researchers might investigate further; please let NMR staff know of new findings. Note that Bruker has another parameter set, DIPSI2ETGPSI19, that provides sensitivity enhancement with 3919 suppression (and presat during d1).